HOW TO FIT GENiEGRiPS® MATS

STEP 1:

Raise Tyne to Waist

SAFELY raise forktynes to waist height.

STEP 2:

Insert Heel

Slide heel hook onto the forktyne.

STEP 3:

Guide Toe Cap

Guide toe cap onto the front tip of the forktyne.

STEP 4:

Slide Heel Hook

Finish by sliding the heel hook behind the heel of the forktyne.

STEP 5:

To Remove

Reverse steps 1-4 to remove GenieGrips.

STEP 6:

Storage

Fold Mats in half and store away neatly on forklift to ensure GenieGrips are easily accessible at all times.

GENIE GRIPS®

ALWAYS:

• Ensure forklift truck is only operated by licensed/trained personnel and in accordance with manufacturer's safe operating procedures.

HELPFUL HINT:

"The installation/removal of GenieGrips® Mats should take no more than 30 seconds, if there is resistance when installing/removing please contact your GenieGrips® representative."