

# MAINTENANCE GUIDE

## GENIEGRIPS® MATS



### STEP 1:

#### Raise Tynes to Waist

SAFELY raise forktynes to waist height.



### STEP 2:

#### Clean Surface

Using warm soapy solution, remove any grease, oil, paint, ice, grit, etc...



### STEP 3:

#### Dry Surface

Using dry cloth remove any moisture or residue.



### STEP 4:

#### Check for Wear & Tear

Over time and general use, you may lose fragments of rubber from the Mats – in particular near the tip. This is standard wear and tear.

However, if your GenieGrips® Mats have excessive tearing and damage to the rubber and/or metal components as in the above images please contact your GenieGrips® representative to order a replacement set.



### STEP 5:

#### Storage of Mats

Fold Mats in half and store away neatly on forklift to ensure GenieGrips® are easily accessible at all times.



### IMPORTANT: Clearance

*"When picking up goods, there must be sufficient clearance above Mats when installed (30mm recommended) to ensure they do not scrape or buckle by forcing against load*

*– see picture on left.*